




# Tip Sheet #12004

## Fleetwood Hydraulic Leveling & Calibration Procedure

© Power Gear 01/13 Tip Sheet 12004 Rev. 0B



## Fleetwood Hydraulic Leveling & Calibration Procedure

**Touch Pad #140-1226 & Control #1010001284  
& Control Box #1010002348**

### Introduction

Procedure to be used to calibrate the Power Gear Automatic Leveling Touch Pad #140-1226 used with Power Gear Automatic Leveling Control Box #1010001284.

**Zero Point:** The zero point is the stored level position; the orientation that the control senses as level. This can only be set when the control is in “calibration” mode. This mode is indicated by all of LED’s blinking on the touch pad.

### Set-Up & Calibration

To recalibrate the control, use the following steps to put the control back into the Zero Point calibration mode.

1. Start the engine, engage the park brake and turn the touch pad on. Transmission should be in park or neutral.
2. Push the “FRONT” button 5 consecutive times and within 10 seconds push the “REAR” button 5 consecutive times. All of the LED’s on the touch pad will begin blinking. this indicates that you have successfully returned the control box to the Zero Point calibration mode.
3. Next set the Zero Point by placing a carpenter’s level on the floor in the center of the coach parallel with the chassis.
4. Push the “FRONT” button until the jacks contact the ground. Once they contact the ground hold the “FRONT” button until the jacks have lifted the coach approximately 2-3”.
5. Push the “REAR” button until the rear jacks contact the ground. Once the rear jacks are on the ground, level the coach using the carpenters level.
6. After front to rear is achieved, turn the level 90° and level the coach from side to side using the “LEFT” and “RIGHT” buttons.
7. To store the Zero Point, push the “All Jacks” button 3 times to store the zero point.
8. After the “All Jacks” button has been pressed 3 times, all of the LED’s on the touch pad will stop blinking except the ON/OFF LED. The ON/OFF and WAIT LED’s will blink for approx. 10 seconds. During this period of time, the control will be looking for one of the following two instructions:
  - a) If there is no air dump or fill feedback to the control, the ON/OFF LED will stop blinking and the AIR DUMP/FILL feature will be disabled.
  - b) If there are air dump and fill feedback to the control, the ON/OFF LED will stop blinking indicating the AIR DUMP/FILL feature is enabled and an audible buzzer will sound for 3 seconds.
9. Upon successful completion of the procedure, the touchpad center green “Power Gear” logo LED will blink continuously.
10. Turn the touch pad off, then back on again, retract ALL JACKS and test the system by pressing the Auto button.

**NOTE: Recheck front to rear level after completing side to side leveling.**



1217 E. 7th Street  
Mishawaka, IN 46544  
info@powergearus.com