



Installation of Revised Top Trim on 900/9100 Series Models

The top trim pieces for 900/9100 Series Models are revised. Brass inserts are now in the top trim piece instead of the cabinet liner of the refrigerator. These revised top trim pieces require a .66 (minimum) clearance hole through the cabinet liner to allow them to fit onto the refrigerator correctly.

If both the top trim piece and the cabinet liner of the refrigerator have brass inserts, follow these instructions to install the top trim piece.

1. Determine the correct location for the clearance holes:

NOTE: You must add two clearance holes to the top trim piece (see illustration below).

- From the center of each hole with the brass insert:
 - Measure .870 toward the center of the refrigerator.
 - Make a vertical mark on the cabinet liner at this point.
 - Through the vertical mark, make a horizontal mark that is level with the center of each hole with the brass insert.
 - The point where the vertical and horizontal marks cross, is the center point for each clearance hole.

2. Drill the two clearance holes:

- Push an awl or an ice pick into the center point for each clearance hole to make a small dent.
- Clamp a piece of scrap wood etc. behind each clearance hole to help prevent the drill bit from breaking the cabinet liner at the top of each clearance hole.
- Using a 11/16 drill bit, carefully drill the two clearance holes.

3. Install the top trim piece:

- Push the top trim piece onto the cabinet liner of the refrigerator:
- Install a screw through each hole of the top trim piece.

