

TUFF/MAXX A/C REPLACEMENT COVER INSTALLATION INSTRUCTIONS

P/N 00-325001

- A.** Two stainless steel fender washers furnished.
- B.** Position stainless steel hold-down plates under bolts or over studs as shown. Use existing bolts or furnished nuts for attachment.
- C.** Align holes or studs with holes in the Tuff/Maxx cover. After sliding the Tuff/Maxx cover down and over previously attached foam pieces shown below; shift the cover to compress foam as needed to achieve proper alignment.
- D.** Apply double sided tape to A/C unit. Place foam pieces in position as shown. Press them on firmly to achieve proper adhesion.

**FOR ASSISTANCE CALL CUSTOMER SERVICE AT
800.780.9893**

Note: This product has a limited lifetime guarantee to the original purchaser. Retain proof of purchase should you need to call.

