# **Serial and Model Number Location Instruction Sheet**

### ATWOOD WATER HEATER

These numbers are located by opening the access door on the exterior of your coach. Inside that door, on the combustion housing there will be a white specification sticker. On that sticker you will find the model and serial number. The model number will begin with either a G or E. The serial number will begin with a "9" and will be 11 or 13 numeric digits long.

#### **HYDRO-FLAME FURNACE**

Locating the Model and Serial Numbers on most Atwood Furnaces is easy. Too help you with this please take a few minutes to familiarize yourself with the probable series of Atwood Furnace you might have. Most 7900/8000-II furnaces are installed in tent trailers and truck campers. Most 8500-IV and 2334 series furnaces are installed in the majority of Trailers, 5<sup>th</sup> Wheels and Motor Homes that Atwood provides heating systems for. 8900-III and 2540/1522 series furnaces are installed in large Class A Motor Homes, Bus's and or structures designed not too be moved.

**IMPORTANT**: Please follow these instructions for locating the Serial Number Sticker and Model Number Sticker for all furnace models that do not have access from the outside of your Coach or Trailer (7900/8000 not included). These Atwood Models are designed to be accessed from the interior of your coach. No outside door will be available or removable to gain this information. Atwood recommends in these situations you contact your selling dealer or nearest servicing dealer for assistance in providing your Serial Number and Model Number. When you are provided your Serial Number as with other Atwood Furnace models the Serial Number will be 7 digits but the Serial number will begin with the Prefix 2LD####.

#### **WEDGEWOOD RANGE**

You will find these numbers by lifting the grates and range top. There is a data plate or sticker in this area. The information you are looking for is on this sticker. **Note:** If you have a "sealed burner" range it is not necessary to lift the top to obtain this information. Instead you can look through the slotted vent area located on the top of the range towards the back.

## **EXAMPLES**

	MODEL NUMBER	SERIAL NUMBER	
Water Heater	G6A-7, GC10A-4E	9610212345	6 (s/n will always start with a "9" and can be 11 or 13 digits long)
Furnace	8535-IV, 7920, 8940, 2334	2509023 2LD35879	(S/N will be 7 digits long,) (S/N for units with no outside (access)
Range	CV32BPN, RV2133W2P	C02041002	(s/n will be one alpha character followed by 8 numeric digits or all numeric up to 13 digits)