

**LIFT GATE BATTERY GUARD**  
STARTING POWER GUARANTEED



## Lift Gate Battery Guard

### Description:

Lift Gate Battery Guard is a simple rugged system that is installed within the power pack of any Lift Gate. Lift Gate Battery Guard constantly monitors the available battery power, if the battery voltage drops below 12.1V or 24.1V uniformly for 2 minutes, the Lift Gate Battery Guard sounds an audible alarm and lights the LED visual warning to alert the operator of low voltage condition.

If the operator ignores this and the battery voltage drops below 12.1V uniformly for four minutes, the Lift Gate Battery Guard disconnects the lift gate motor to ensure sufficient power for engine starting is preserved. To restore power to the lift gate, the operator needs to start the engine and put some charge back in the battery, power to the lift gate will then be restored.

Lift Gate Battery Guard is available in 12V & 24V and is supplied in a ready to install system.

12V Lift Gate Battery Guard part No 10-00698-012

24V Lift Gate Battery Guard part No 10-00698-024

### Part Number:

 10-00698-012  
10-00698-024

### Key Features:

- OEM or Aftermarket install
- Visual & Audible warning of low battery voltage
- Fully waterproof with Delphi Packard connectors
- Night silent input via side light feed (lights on audible alarm mute)
- Reliable proven rugged design