T.I.P. Troubleshooting Information on Power Gear


1217 E. 7th Street Mishawaka, IN 46544 Phone: 1-800-334-4712 1-888-339-2539 Fax: 574-256-6743

VERTICAL HEIGHT ADJUSTMENT ON SLIDE-OUT SYSTEM

Each rail of the slide-out system has individual vertical height adjustment. Set the vertical height using the procedure shown below.

With the room extended completely adjust room height by-

- 1. Loosening the 3 bolts in the vertical adjustment slots.
- 2. Using the appropriate sized Allen head wrench, turn the vertical adjustment bolts either clockwise or counter-clockwise to raise or lower room (depending on the need).
- 3. Check room height setting. Repeat step 2 until height is set to proper location.
- 4. Tighten the 3 bolts in the vertical adjustment slots.



TIP Sheet #150 82-S0314-T 03-02