THETF#RD

RV Toilet Service Parts

for Aria/Aria Deluxe

Tools needed

- · Flat-blade screwdriver
- Adjustable Wrench (if removing Toilet from floor)
- Stubby Phillips screwdriver (if not removing Toilet)

Notes:

- · Read all instructions before beginning work.
- If there is enough clearance behind toilet, this procedure may be possible without removing toilet from floor.

To Remove Old Part

- 1. Pop up Screw Covers (hinged from rear).
- 2. Holding Hinge Post Nuts from inside, turn screwdriver

If Necessary To Remove Toilet From Floor:

- 1. Turn off RV water supply per RV Owner's Manual.
- 2. Press both keypad buttons at the same time, twice, to open blade and drain bowl of water.
- 3. Pry off Bolt Caps with Flat-blade screwdriver. Use wrench to remove 1/2-inch Lag Screws.
- 4. Swivel Toilet to gain access to back.
- 5. Turn off RV's power supply to the Toilet.
- 6. Disconnect Water Supply Line with Adjustable Wrench.
- 7. Disconnect Toilet's 12-volt power hookup to RV.
- 8. Place an old towel or soft cloth on work surface. Remove Toilet from floor and place upright on work surface.
- 9. Remove old Closet Flange Seal (may be found in toilet or in floor at Closet Flange). Discard.
- 10. Cover Holding Tank opening to contain odor.

To Replace Toilet To Floor

- 1. Secure new Closet Flange Seal, lip side up, to Toilet.
- 2. Position Toilet over flange.
- 3. If necessary, reconnect Water Supply Line.
- 4. If necessary, reconnect 12-volt power supply.
- 5. Reconnect RV's power supply to the Toilet.
- 6. Turn on RV's water supply. Press Toilet flush button to close blade and to flush test.
- 7. Secure to floor with Lag Screws. Tighten.
- 8. Resecure Bolt Caps.

Seat and Cover Assembly Part #19614 (White) Part #19709 (Bone)

counterclockwise to unscrew Hinge Posts. (See drawing for location of bolts on inside. Access may be made easier by removing Metal Bracket. Use stubby Phillips screwdriver.) Remove and discard old Nuts and Bolts.

3. Pry off Hinge Covers with screwdriver. Discard old Seat and Cover Assembly. Clean remains of adhesive with mineral spirits.

To Replace Part

- Peel off one side of paper covering each of two new adhesive pads. Apply to each of new Seat and Cover Assembly Hinges.
- 2. Peel off other side of paper covering adhesive pad. Place Bolts through Hinge holes. Position new Seat and Cover Assembly over holes in china. Center over bowl before pressing Hinges down to adhere.
- 3. Hand tighten Nuts. Tighten with screwdriver.
- 4. If you have removed the Metal Bracket, reattach it. Tighten the screws with stubby Phillips screwdriver.

