

QuikChek instructions





3. Wait for spark.

Meanwhile:

0


(Depending on the board, this

will take up to 20 seconds.)

Power light will come on, NC light may come on.



4. When spark starts. Valve light will come on. <u>Press Flame button</u> Spark should stop. Valve light should remain on.



End of test.

QuikChek instructions Important Considerations

- For use on 12v DC ignitor boards only. (Not for use on "park model" - 24v AC boards.)
- 2. Will not test the sense circuit of boards that use an external sense wire.
- 3. Always connect the tester to the board before plugging the tester into the cigarette lighter. (Otherwise, the board may start sparking before you connect the spark connector - not fun!)
- 4. If the power light does not come on when you plug the tester into the cigarette lighter, turn on the ignition switch and/or wiggle the plug.(The board won't fire if the power light is not on.)
- 5. If the NC light does not come on, don't worry some boards will not turn it on.