

To select the optimal generator model to meet your RV power needs, add the combined wattage or amps of all appliances & equipment you might typically use at one time. Then choose a generator with an electrical output ability that is higher than the combined wattage of all the items you plan to operate simultaneously.

Appliances	Average Required Wattage	Approx. Amps
Air Conditioner	1,400-2,400	9-20
Battery Charger	up to 3,000	6-28
Blender	600	5.5
Broiler	1,350	12
Coffeepot	550-1,000	4-8
CD Player & Speaker	50-100	0.5-0.9
Computer	50-100	0.5-0.9
Converter	500-1,000	4-8
Curling Iron	20-50	0.2-0.5
Dishwasher	1,400	12
Electric:		
Blanket	50-200	0.5-1.5
Broom/Vacuum	200-500	1.5-4
Drill	250-750	2-6
Fan	25-100	0.2-0.9
Frying Pan/Wok	1,000-1,350	8-11
Stove (per element)	350-1,000	3-8
Water Heater	1,000-1,500	8-13
Water Pump	500-600	4-5
Hair Dryer	350-1,500	3-13
Iron	500-1,200	4-10
Lightbulbs	40-100 each	0.36-0.9
Microwave	700-1,500	6-13
Radio	50-200	0.5-1.5
Refrigerator	400-1,000	3-8
Sewing Machine	125	1.0
Space Heater	1,000-,1500	8-13
Television	200-600	1.5-4
Toaster	750-1,200	6.5-10
Washer/Dryer	2,000-2,250	16
VCR	150-200	1.15